



LIQUOR CONTROL OPTIONS

GEN: General Options		Station #	
	Features	1-255	Station #
+1	Sales Open		
+2	Enable Bottle SKU Database		
Choice of Language			
+4	Enable Price Level Schedule	+0	French
+8	Enable Price List	+1	English
+64	Enable Event Schedule	+2	Spanish
+128	Enable Owner Protected Program (OPP)	+3	Portuguese
Scanner port			
+16	Activates ECR Scanner port		
Contrast			
+48	Activates Berg compatible interface (06=ACK required from the controlling device)	1-22	Contrast on the screen (+6 Standard)
GEN2: General Options 2			
Interval			
	Default portion	45	100 = 1 imp.oz portion
+0	Portion 1 is the default portion		
+1	Portion 2 is the default portion		
+2	Portion 3 is the default portion		
+3	Portion 4 is the default portion		
SCAN: Scanner/ ECR Interface			
PLU Options			
+4	Return to above default portion after 15 sec.	+1	Send 12 digit PLU (099999 XXXYY)
+8	Return to above default portion after 30 sec.	+0	YX (Spout Y, Portion X)
+12	Return to above default portion after 45 sec.	+2	1YX (Spout Y, Portion)
+16	Return to above default portion after each pour	+4	10YX (Spout Y, Portion)
	Inter-PLU Delay	+6	100YX (Spout Y, Portion)
+0	No delay	+8	Use PLU Stored in memory
+32	500ms delay		
+64	1sec. Delay	+16	When the ECR Scanner Port is activated
+96	1.5 sec. Delay	+32	Activates the check digit required by certain ECRs
+128	Phase x CRC CCITT-8408	+64	Adds a prefix byte before the PLU
		+128	Removes the line feed (0x0D)
			Removes the carriage return (0x0A)
GEN3: General Options 3			
Auto-Repeat			
+1	Enable Auto-Repeat Feature	+16	When the Berg compatible interface is activated
+2	Auto-Repeat delay Add 0.250 sec	+32	Extends communication delay (add 1 sec.)
+4	Auto-Repeat delay Add 0.500 sec	+128	Extends communication delay (add 1 sec.)
+8	Auto-Repeat delay Add 1 sec		Does not wait for a confirmation (No ACK Required)
+16	Activation delay add 0.25 sec.		
+32	Activation delay add 0.5 sec.		
PREFIX1: Prefix (for SCAN + 32) *			
		+2	CRS3000 Scanner Interface
		+65	Uniwell Scanner interface
GEN4: General Options 4			
+16	Station is designated as a slave.		
+32	Station is designated as a master.		
PREFIX2: Prefix (for SCAN + 32) *			
+64	Enable free pour when setting portions.	+2	CRS3000 Scanner Interface
+128	Bypass Fingerprint Check When Pouring	+65	Uniwell Scanner interface
COMM: Communication Options			
Reporting			
+0	6 extra line feeds at the end of report	HRS	PRICELV:Price Level Schedule *
+1	9 extra line feeds at the end of report	99	PLV default and days
+2	12 extra line feeds at the end of report		DISABLE
+3	15 extra line feeds at the end of report	00-23	Set Price Level 1
+4	Will not print out reports while in the RUN mode	00-23	Set Price Level 2
		00-23	Set Price Level 3
		00-23	Set Price Level 4
Parity			
+0	No parity	00-23	Set Price Level 5
+16	Odd parity	00-23	Set Price Level 6
+48	Even parity	00-23	Set Price Level 7
		00-23	Set Price Level 8
Baud rate			
+0	1200 Baud rate		
+64	2400 Baud rate		
+8	4800 Baud rate	HRS	EVNT SC.: Event Schedule *
+128	9600 Baud rate	99	DISABLE
+192	19200 Baud rate	00-23	Close
+72	28800 Baud rate	00-23	Open
+136	38400 Baud rate	00-23	Print X2 Report
+200	57600 Baud rate	00-23	Print Z2 Report
		00-23	Reboot Station
PRICELVL: Price Levels			
1-8	Activate that number of price levels		

* FUNCTION MUST HAVE BEEN ENABLED*